# Depth Adjustment

- 1. Lift feed handle.
- 2. Back depth adjustment screw out to stop.
- 3. Tighten adjustment screw number of turns shown opposite pipe/tube to be grooved.

Note: Make test groove to check groove diameter.

### 1 1/4 - 2in. & 2 - 6 in. Roll Set

Pipe Diameter	Sch. 10 No. of turns	Sch. 40 No. of turns
6	2 ½	N/A
4	2 3/4	N/A
3 ½	2 3/4	N/A
3	2 ½	3/4
2 ½	2 ½	1
2	2 ½	1 ½
1 ½	2 ½	1 3/4
1 1/4	2 ¾	1 ¾

# Copper Roll Set (Optional)

Tubing Diameter	Copper Tubing Type No. of turns			
	K	L	M	DWM
6	1 1/4	2 ½	3	4 1/4
5	1 3/4	2 3/4	3 1/4	4 1/4
4	2 ½	3 1/4	3 ½	4 1/2
3	3 1/4	3 ½	4 1/4	4 3/4
2 ½	3 ½	4	4 1/4	N/A
2	4	4 1/4	4 1/2	N/A

### 1 Inch Roll Set (Optional)

Pipe Dian	netet	Sch. 10 No. of turns	Sch. 40 No. of turns
1		5	4 1/4

# 1 ¼ - 1 ½ Inch Roll Set (Optional)

Pipe Diameter	Sch. 10 No. of turns	Sch. 40 No. of turns.
1 ½	3 ¾	3
1 1/4	3 ½	3